


0006 – Callahan



Contents

Important Warnings & Safety 2

Electrical Safety..... 3

Battery Safety (main device)..... 3

Remote Control & Battery Safety 4

Product Description 4

Compliance Statement..... 5

Cleaning and Storage..... 6

TROUBLESHOOTING..... 7

DISPOSAL INFORMATION 8

Important Warnings & Safety

- Consult a healthcare professional if you have specific concerns.
- Adult use only: This product is intended for adults only and must be kept out of reach of children.
- Supervised use when needed: Individuals with reduced physical, sensory, or mental capabilities, or limited experience, should use the product only with proper supervision or clear instructions for safe use.
- Use as intended: Operate the product for its designed and intended purpose.
- Avoid sharing devices: Sharing intimate products can transmit infections. Use them only with your partner and consider protective measures when appropriate.
- Check condition before use: Do not use the product if you notice cracks, tears, or any signs of material degradation.
- Handle and store properly: Keep the product off absorbent surfaces to prevent staining; if the device malfunctions, switch it off and consult the support resources on the website. Do not bend or stretch the device product if not explicitly mentioned as a feature.
- Do not use damaged components: If any part of the product is damaged, discontinue use immediately.
- WARNING: Keep new and used batteries away from children.

Electrical Safety

- This product must only be powered by a certified Safety Extra-Low Voltage (SELV) source (5V DC).
- Use only standard USB power supplies rated 5V DC (e.g., USB charger, power bank, or computer USB port).
- Do not connect the product directly to mains power.
- Do not use the product while charging.
- Use only certified charging equipment that meets applicable safety standards.

Battery Safety (main device)

This product contains a rechargeable lithium-ion battery.

- Do not expose the product to fire, excessive heat, or direct sunlight.
- Do not place the product near heat sources or in high-temperature environments.
- Do not pierce, crush, disassemble, or attempt to modify the product.
- Do not use the product if it shows signs of damage, swelling, leakage, or unusual odor.
- Charge the product only with the provided cable and a certified 5V USB power supply.
- Do not charge the product unattended or for extended periods beyond full charge.
- If the product overheats, emits an unusual smell, or malfunctions, disconnect it from the power source immediately and discontinue use.
- Dispose of the product in accordance with local regulations for electronic waste. Do not dispose of it in household waste.

Remote Control & Battery Safety

The included remote control uses a coin cell battery (e.g., CR2032 or equivalent).


- Keep coin batteries out of reach of children at all times.
- Swallowing a coin battery may cause serious injury or internal burns.
- If a battery is swallowed, seek immediate medical attention.
- Use only the specified battery type.
- Do not mix old and new batteries.
- Insert the battery with correct polarity.
- Remove the battery if the remote control will not be used for an extended period.
- Do not recharge, disassemble, or expose the battery to fire or excessive heat.
- Dispose of used batteries in accordance with local regulations.

Product Description

The product is a G-spot Vibrator.

Intended Use

This product is intended for stimulation as depicted below.



Key Features

- **Ergonomic curved design** for precise application
- **10 customizable vibration modes** for a personalized experience
- **Powerful yet quiet motor** for smooth, consistent performance
- **Premium materials:** Body-safe silicone + durable ABS
- **Soft-touch finish** for enhanced comfort and control

Smart Control & Convenience

- Includes remote control (battery powered) for enhanced usability
- Cordless design for maximum freedom and portability
- Ideal for at-home adventures, relaxation or travel

Product Specifications

- **Material:** Safe silicone/ABS
- **Modes :** 10 Modes
- **Product Battery Capacity :** 3.7V/380mAh
- **Charging Time :** 120 min
- **Using Time :** 90 min
- **Color:** Black
- **Length:** 7.19 inches / 182.5 mm
- **Diameter:** 1.16 inches / 29.5 mm

- **Water Resistance:** IPX6
- **Charging:** USB rechargeable with magnets
- **Noise Level:** ≤50dB

Charging Instructions

- Please fully charge the product for the first time you use it.
- Please use the included magnetic charging cable to charge the product; you can use your phone charger, power bank, computer or car charger to connect with the cable.
- Please place the product on the table when charging. Do not hang or suspend the product by the charging cable, as this may interrupt charging.
- Please note that the product cannot be turned on while charging. Please remove the cable before turning it on.
- The LED indicator will be flashing when charging; it will become constant light when it is fully charged.

Compliance Statement

WARNING: Any changes or modifications not expressly approved in writing by the responsible compliance authority may void your permission to operate the device and may also invalidate any applicable warranties.

This product is subject to FCC rules and is currently undergoing FCC authorization. Shipment to the end user will occur only after FCC authorization is completed. If FCC authorization is not completed, your order will be fully refunded. FCC rules do not address applicable consumer-protection, contractual, or other federal or state law rights.

Declarations are available for download on myplotmate.com.

Responsible Party (USA):

myplotmate LLC
4653 Carmel Mountain Rd Ste 308 #AA203
San Diego, CA 92130, USA
Email: support@myplotmate.com

Cleaning and Storage

Using hand creams or silicone-based lubricants may damage the surface permanently.

The product is fully waterproof and easy to clean. Rinse it, apply a product cleaner, rinse again, and allow it to dry. Always clean thoroughly before and after each use. You can also wash it with warm water and antibacterial soap, then rinse with clean warm water and dry with a lint-free cloth.

Do not use cleaners containing alcohol, petrol, or acetone. Keep the product away from direct sunlight and never expose it to extreme heat. Store it in a clean, dust-free place, separate from other materials.

TROUBLESHOOTING

Please get in contact with support@myplotmate.com if you face any problems with the product.

DISPOSAL INFORMATION

This product contains electronic components and should be recycled or disposed of properly in accordance with local laws and regulations. Do not dispose of this product in household trash where e-waste recycling programs exist.

For information on recycling facilities in your area, contact your local waste management authority. Recycling services may not be available in all areas.

DISCLAIMER: Use of this product is at the user's own risk. Neither myplotmate nor its retailers accept any responsibility or liability arising from its use. Any changes or modifications not expressly approved by the manufacturer may void the user's authority to operate the device. Specifications and design are subject to change without prior notice for the purpose of product improvement.

© 2026 myplotmate LLC. All rights reserved. myplotmate, 4653 Carmel Mountain Rd Ste 308 #AA203, San Diego CA 92130, United States.

Designed by myplotmate in the USA. Made in China.